

#### SAFETY INSTRUCTION



**READ CAREFULLY BEFORE INSTALLING FIXTURE. PLEASE KEEP THIS MANUAL FOR FUTURE USE.** Fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.


MAKE CERTAIN POWER IS OFF BEFORE INSTALLING OR MAINTAINING FIXTURE. CHECK THAT VOLTAGE IS COMPATIBLE WITH FIXTURE DRIVER. USE APPROVED CONNECTORS FOR ALL ELECTRICAL CONNECTIONS.

#### **MAINTENANCE CAUTION**




- 1. Review the wire connection before beginning, and make sure fixture is grounded properly.
- 2. For lighting controls, follow control instructions carefully.
- 3. Turn power off and wait for fixture to cool before performing maintenance.
- 4. Maintenance must be done by professionals.

## DIMENSIONS



### WIRE CONNECTION




Add: 1135 Thomas Busch Highway, Pennsauken, NJ 08110 Phone: 866-222-8866 E-mail: info@abovealllighting.com 1 Web: www.AboveAllLighting.com ©2016 ABOVE ALL Lighting, Inc. All rights reserved



### INSTALLATION

#### WARNING


Risk of injury or damage. Make certain power is OFF before installing or maintaining fixture.



Add: 1135 Thomas Busch Highway, Pennsauken, NJ 08110 Phone: 866-222-8866 E-mail: info@abovealllighting.com <sup>2</sup> Web: www.AboveAllLighting.com ©2016 ABOVE ALL Lighting, Inc. All rights reserved



# SCELEY LED BOLLARD Instructions Manual



# WATTAGE AND CCT SELECTABLE

